



Assembly Instructions for Prevue Pet Model #42614

Step 1: Unfold bottom body mesh piece and set on flat surface. Bottom body mesh is flat on top.

Step 2: Unfold top mesh piece and attach to bottom mesh piece using wire hook and eye closures on the cage sides. **Before engaging hook and eye closures, place the top mesh piece behind the two wires on the top of the bottom mesh piece.*

Step 3: Insert cage mesh into cage base. The front of the cage mesh should be on the same side as the front of the base (where the drawer pulls out).



Step 4: Place grille in bottom of cage.

Step 5: Insert cups and perches as shown.

Step 6: Attach cage roof mesh to the top of the cage.

Your new cage is ready to use!

Parts Included for model #42614

- | | |
|----------------------------|-----------------------|
| 1 top mesh piece | 1 mesh grille |
| 1 bottom mesh piece | 4 wood perches |
| 1 mesh roof piece | 2 plastic hooded cups |
| 1 plastic base with drawer | |