



## Assembly Instructions for Prevue Pet Model #856

Step 1: Unfold body mesh piece and set it on a flat surface.

Step 2: Hook the two middle pieces to the back of the cage mesh so all of the body mesh is secured together.



Step 3: Insert body mesh into cage base by snapping the body mesh into the clips in the base (3 clips on each long side). Also make sure the body mesh fits inside the open channels along the short sides of the base.

Step 4: Attach the 3 roof pieces (2 peaked and 1 round). Attach the round roof piece first by hooking it underneath the middle pieces of the body mesh. The peaked roof pieces are exactly the same and can be used on either end of the roof.

Step 5: Place perches inside the cage as desired. Place cups inside cage so they are held in place by the cup doors.

Step 6: Slide in the bottom grille & tray through the opening on the end of the base. Your new cage is ready to use!

### Parts Included for Model #856

- |                            |                                     |
|----------------------------|-------------------------------------|
| 1 mesh bottom grille       |                                     |
| 1 mesh cage body           | 2 plastic perches with plastic tips |
| 3 mesh roof pieces         | 2 plastic hooded cups               |
| 1 plastic base with drawer |                                     |